

SAFE BESCHREIBUNG

NEUEN ZAHLENCODE PROGRAMMIEREN

Safetür öffnen

Knopf bei den Safescharnieren in der Innenseite betätigen – für Reset (Piepston)

4-stellige Nummer innerhalb von 10 Sekunden eintippen

Taste B zur Bestätigung drücken (Safe entriegelt noch nicht)

SAFE ÖFFNEN

4-stellige Nummer eintippen und mit der Taste B bestätigen

Grünes Licht leuchtet auf
Drehverschluss nach rechts drehen

ACHTUNG! Gegenstände nicht vergessen und Türe vor der Abreise geöffnet lassen!

WLAN

Das WLAN ist für unsere Hausgäste kostenlos und für mehrere Geräte pro Apartment verfügbar.

Passwort: **gond**e**blick2009**

SAFE DESCRIPTION

PROGRAMMING A NEW NUMERICAL CODE

Open the door

Press the button at the safe hinges on the inside – for reset (beep sound)

Type in a 4-digit number within 10 seconds

Press the B button to confirm

OPENING THE SAFE

Type in the 4-digit code and confirm it by pressing the button B

Green lamp lights - Open the safe by turning the screw top to the right

ATTENTION! Don't forget your personal belongings and leave the safe opened!

WLAN

The WLAN is free of charge for our house guests and available for several devices per apartment.

Passwort: **gond**e**blick2009**